








## ESPAÑOL


**1.** Distribuir la estructura en el suelo sobre una lona protectora. Ensamblar la estructura del techo acorde al diagrama. Colocar las patas a media altura. **2.** Colocar la lona cuidadosamente sobre la estructura. Empiece por la parte trasera. **3.** Haga coincidir las esquinas de la lona con los codos de la estructura. **4.** Levante las patas cuidadosamente. Especial atención a no doblar la estructura y no dañar la lona con los tubos. **5.** Cerrar las cremalleras. Clavar completamente la tienda. Primero las esquinas traseras, y después las frontales. Clavar el resto dando tensión adecuada.

## ENGLISH

**1.** Lay out the components of the frame over a protective sheet. **2.** Assemble the poles that constitute the roof of the tent and attach the leg poles (back legs are longer). Set the legs at a height you can reach easily. Take the canvas and lay it over the freestanding tent frame. **3.** Extend the roof bars. **4.** Before extending the leg poles, place the feet onto the second step of the corresponding rubber ladders attached to the bottom of the freestanding tent. Extend to full height. Close all zips completely. Apply tension to the roof poles. **5.** Now is the best time (before pegging) to situate the freestanding tent in the desired position. Peg the freestanding tent on both sides at the rear, then the front corners. Working from the back outwards, peg the remainder of the sides. Finally, peg the back and front edges, thus completing the assembly of your freestanding tent.

## Accesorios

Loetas  
33 x 33 cm



Colgador Cocina  
Kitchen hanger

